

## ► SW42DA

### User Manual

## Thank you for purchasing this product.

For optimum performance and safety, please read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.



## Surge Protection Device Recommended

This product contains sensitive electrical components that may be damaged by electrical spikes, surges, electric shock, lightning strikes, etc. Use of surge protection systems is highly recommended in order to protect and extend the life of your equipment.



## Eco Friendly Packaging

This product has been packaged with fully recyclable materials, including compostable bags. Please help us to protect the environment.

## Safety and performance notice

Do not substitute or use any other power supply other than approved Blustream power supplies.

Do not disassemble the SW42DA unit for any reason. Doing so will void the manufacturer's warranty.

# Contents

Introduction	03
Front Panel	04
Rear Panel	04
Resetting the SW42DA	05
Operations and Connections	05
EDID Management	06
2 Channel Line Outputs	06
Web-GUI - Log In and Initialisation	07
Web-GUI - Control	09
Web-GUI - Input	10
Web-GUI - Output	11
Web-GUI - Audio	13
Web-GUI - Dante® Module Settings	18
Web-GUI - Dante® Module Update	19
Web-GUI - Dante® Module Information	20
Web-GUI - Users	21
Web-GUI - Settings	22
Dante® Controller	26
Advanced Dante® Settings	27
Specifications	28
Package Contents	28
Acknowledgements	28
RS-232 Configuration and Telnet Commands	29
Certifications	33

## Introduction

 Dolby Atmos

 dts X

The Blustream SW42DA is a 4-Way HDMI switch that has been designed to breakout, convert, and downmix embedded Dolby Audio® or DTS Audio within a HDMI switching environment.

The SW42DA will pass native video with the embedded multi-channel audio to compatible equipment on output 1, with a second HDMI output featuring optional video down-scaling from 4K 60Hz 4:4:4 or 4:2:0, video down to 1080p, with the native embedded audio, or down-mixed 2ch audio as required.

Audio capabilities include the selection and manipulation of formats across both multichannel and 2ch downmixed. The Dante® output allows for 9.1ch breakout and embedding into a Dante® digital signal, and/or 7.1ch breakout with a separate 2ch down-mixed Dante® output. Optical S/PDIF breakout (2ch or 5.1ch as required), individual analogue multi-channel breakout, and 2ch downmixed balanced/unbalanced analogue audio can also be broken out as required directly from the unit.

The SW42DA provides an advanced, but cost effective solution for ensuring that 4K UHD video and multi-channel audio can be distributed around a Dante® multi-room system where there are a mixture of 2ch and/or 7.1ch zones or 7.1.2ch / 5.1.4ch (9.1ch) audio, with multiple output resolution requirements. Perfect for cinema and media room set up's where local content would be shared within a multi-zone distributed system where either multichannel or down-mixed audio is required.


### FEATURES:

- Features 4 x HDMI inputs which can be switched to the dual HDMI outputs simultaneously
- Supporting Dolby Atmos® Technology
- Supports HDMI 2.0b 18Gbps specification, including 4K 60Hz 4:4:4 UHD video
- Supports distribution of the latest HDR resolutions including HDR10/10+ and Dolby Vision
- HDMI output 1 replicates the HDMI input signal - up to 4K 60Hz 4:4:4 and 5.1.4ch / 7.1.2ch Dolby Atmos® and DTS-HD multi-channel audio
- HDMI output 2 features an optional 4K video down-scaler, and 5.1.4ch / 7.1.2ch to 2ch Dolby Atmos® and DTS-HD audio downmixing
- Supports all known HDMI audio formats including Dolby TrueHD, Dolby Atmos, Dolby Digital Plus and DTS-HD Master Audio transmission
- HDMI audio breakout of Dolby Atmos® and DTS-HD to up to 8 channels of Dante® audio (7.1ch), with an independent 2 down-mixed channels of Dante audio
- HDMI audio breakout of Dolby Atmos® and DTS-HD to up to 10 channels of Dante® audio (7.1.2ch / 5.1.4ch)\*
- HDMI audio breakout to 7.1ch balanced / unbalanced analogue audio outputs
- HDMI Dolby Atmos® and DTS-HD 7.1 down-mixing to 2ch balanced and unbalanced audio outputs
- Supports ARC/eARC including breakout to 7.1ch and 2ch downmixed analogue, and Dante® audio
- Supports: 44.1, 48, 88.2 & 96kHz Dante® sample rates @ 24-bit
- Configurable Dante® device latency using Dante® Controller
- Supports AES67 RTP audio transport
- Control via TCP/IP, web-GUI, RS-232, front panel buttons, and infrared
- HDCP 2.3 compliant with advanced EDID management

**Please note:** The Dante 2ch down-mix channels can be re-allocated to allow for additional height channels (7.1.2ch / 5.1.4ch)


® Dolby Audio is a registered trademark of Dolby Laboratories Licensing Corporation.

## Front Panel



- ① IR Receiver Window
- ② LCD Display — Shows the status of input/output selection, EDID, etc...
- ③ Input 1 Select Button
- ④ Input 2 Select Button
- ⑤ Input 3 Select Button
- ⑥ Input 4 Select Button
- ⑦ Menu Button
- ⑧ Power Button — Press and hold for 3 seconds to power ON / OFF
- ⑨ Left Button / Volume Down
- ⑩ Right Button / Volume Up
- ⑪ Up Button / Volume Mute
- ⑫ Down Button
- ⑬ Confirm Button
- ⑭ Cancel Button — Press and hold to factory reset

## Rear Panel



- ① L/R Analogue Audio Outputs — 8 x balanced/unbalanced phoenix connectors
- ② L/R Analogue Audio Outputs — 2 channel downmixed balanced/unbalanced phoenix connectors
- ③ Optical Audio Output — Toslink (S/PDIF) connector
- ④ HDMI Input 1-4
- ⑤ HDMI Output 1 — Bypass video output maintains native video resolution and audio format
- ⑥ HDMI Output 2 — Scaled / down-mixed output
- ⑦ Dante® Port — RJ45 socket connects Dante® Network
- ⑧ TCP/IP Network Connection — RJ45 connector
- ⑨ EDID DIP Switches — Adjust the EDID setting for the source input (see page 6 for more details)
- ⑩ RS-232 Port — 3-pin Phoenix connector
- ⑪ Network Mode Switch — Mode 1 & Mode 2 (see page 5 for more details)
- ⑫ IR Input — 3.5mm stereo jack
- ⑬ IEC Power Connector

**Please note:** The 2 channel downmixed outputs can be assigned as height speakers in a 7.1.2 channel and a 5.1.4 channel configuration.

**Please note:** The optical audio output can operate in 2 channel downmix mode or in bypass mode (supports 5.1 channel).

## Resetting the SW42DA

To reset the SW42DA back to factory default, press and hold the cancel (x) button on the front panel until the screen displays: 'FACTORY RESET?'

Press the confirm (v) button.

The reset process takes approximately 30 seconds.

## Operation and Connections

Basic operation of the SW42DA can be achieved via the front panel: connect the HDMI source devices, the analogue audio outputs, the HDMI outputs, and power to the rear of the unit:

- Buttons 1-4 will switch between the HDMI inputs
- The Menu Button will scroll through a few functions of the SW42DA such as EDID, Network and Dante® configuration
- The menu can be navigated using the arrow, confirm and cancel buttons

EDID for the HDMI source can be manually set using the DIP switches on the rear of the unit. Please refer to the EDID Management section of the manual for DIP switch settings.

The SW42DA features two RJ45 ports. Functionality of these ports can be controlled by selecting the Network Mode on the rear of the unit, allowing the SW42DA to suit the needs of the installation:

- Mode 1: The Dante® port allows connection to Dante®, TCP/IP and the Web-GUI
- Mode 2: The Dante® port allows connection to Dante®. The TCP/IP port allows access to TCP/IP and the Web-GUI

The IR EXT port can be used to control the SW42DA via the included remote when the IR Receiver Window is obstructed, or via a 3rd party control processor.

For full configuration of the SW42DA, the in-built Web-GUI must be utilised

## EDID Management

EDID (Extended Display Identification Data) is a data structure that is used between a display and a source. This data is used by the source to find out what audio and video resolutions are supported by the display, then from this information the source will determine what the best resolution is to output.

While the objective of EDID is to make connecting a digital display to a source a simple plug and play procedure, issues do arise when multiple displays or video matrix switching is introduced because of the increased number of variables.


The SW42DA will act as an 'end point' in the HDMI signal path. Using the EDID dip-switches predetermines the video resolution and audio format of the source, regardless of the video output resolution that the SW42DA scales to.

To change the EDID settings move the EDID dip-switches as required on the front panel of the unit. Please see below table for settings:

3	2	1	0	EDID Type
<i>Combination of DIP positions</i>				
0	0	0	0	1080p 60Hz 2.0ch
0	0	0	1	1080p 60Hz 5.1ch
0	0	1	0	1080p 60Hz 7.1ch
0	0	1	1	4K 60Hz 4:2:0 2.0ch
0	1	0	0	4K 60Hz 4:2:0 5.1ch
0	1	0	1	4K 60Hz 4:2:0 7.1ch
0	1	1	0	4K 60Hz 4:4:4 8bit 2.0ch
0	1	1	1	4K 60Hz 4:4:4 8bit 5.1ch
1	0	0	0	4K 60Hz 4:4:4 8bit 7.1ch
1	0	0	1	4K 60Hz 4:4:4 10bit 2.0ch
1	0	1	0	4K 60Hz 4:4:4 10bit 5.1ch
1	0	1	1	4K 60Hz 4:4:4 10bit 7.1ch
1	1	0	0	DVI 1920x1080 No Audio
1	1	0	1	DVI 1920x1200 No Audio
1	1	1	0	Copy from Output 1
1	1	1	1	Software Control

## 2 Channel Line Outputs

The 2 channel line output can be assigned as a 2ch downmixed audio signal, or re-allocated as additional height speakers when decoding 7.1.2ch or 5.1.4ch signals. The analogue output can be wired with balanced or unbalanced audio devices with the pin out as adjacent.



# Web-GUI - Log In and Initialisation

The following pages will take you through the operation of the unit's Web-GUI. You must connect a TCP/IP RJ45 socket to your local network, or directly from your computer to the SW42DA, in order to access the product's Web-GUI.

By default, the unit is set to DHCP; however, if a DHCP server (eg: network router) is not installed, the unit's IP address will revert to below details:

Default IP Address is: [192.168.0.200](http://192.168.0.200)      Default Admin Username is: [blustream](#)      Default Admin Password is: [@Bls1234](#)

If the IP address of the SW42DA is not known, it can be found by:

- Using the front panel buttons to scroll to the IP address
- Using a 3rd party IP scanning tool
- Using RS-232 connection and sending 'STATUS' command; this will return all settings of the SW42DA
- Using the default hostname address: [sw42da.local](http://sw42da.local)

When initially accessing the Web-GUI of the SW42DA, the Guest Control page is shown as below. Permissions for the Guest can be set so as to restrict control of the unit for users who are not logged in.




### Login Page:

The Web-GUI supports multiple users along with multiple user permissions as follows:

- Admin (Blustream) The Admin account allows full access to all functions and configuration of the unit.
- User Accounts User accounts can be utilised, each with individual login details and can be assigned permissions to specific inputs and functions.
- Guest The Guest user can access the control page without logging in.


**Please note:** The guest user should have permissions set to prevent unwanted access, as they do not require credentials for control of the unit.



**Please note:** the first time the Administrator logs into the Web-GUI of the SW42DA, the default password must be changed to a unique password. Please retain this password for future use. Forgetting the password will mean having to factory reset the unit, losing all prior network and configuration settings.

New password regulations require passwords being set for products to be a minimum of 8 characters and contain a minimum of: 1 x uppercase letter, 1 x lowercase letter, 1 x symbol and 1 x number.

Passwords can be changed as required within the Web-GUI of the unit once logged in.



# Web-GUI - Control

Once logged in as the Administrator, additional Web-GUI pages become available from within the GUI: these can be navigated to by pressing the corresponding icon.

The Control page allows for source selection and the master volume level to be set or muted.



## Source Select:

The input source can be selected from one of the HDMI inputs by pressing the corresponding button. This will set the source for both HDMI Output 1 & HDMI Output 2 (mirrored).

All levels sections across the Web-GUI feature the same controls for each of their respective channels. Volume can be adjusted by using the corresponding slider for the desired channel. Fine-tuning of the volume can be achieved by using the decrement button ① or the increment button ③, or by manually inputting the value ②. The output can be muted by pressing the mute button ④.



## ARC:

The Audio Return Channel (ARC) or Enhanced Audio Return Channel (eARC) on HDMI Output 1 can act as a source or an output.

When set as a source, ARC/eARC will be assigned as input 5 on the SW42DA, resulting in ARC/eARC audio for all audio outputs, but no video signal on HDMI 1 & 2 outputs.

When set as an output, ARC/eARC can be enabled or disabled via a toggle.

When enabled, HDMI Output 1 will only output video. HDMI Output 2 will output the selected source audio and video. This allows you to use HDMI Output 2 for additional HDMI distribution purposes. ARC/eARC will be output to the Line and Dante® audio outputs.

When disabled, HDMI Output 1 & 2 won't be affected.

**Please note:** HDMI ARC and eARC is only supported on HDMI Output 1



# Web-GUI - Input

The Input Page allows for source configuration and EDID management.

Clicking the 'Update' button to the right of each input allows for the name of the source to be entered. This name is updated across the Web-GUI globally for simpler selection of inputs.

Name	HDMI Cable	EDID	Actions
INPUT1	Disconnected	HDMI 1080p@60Hz, Audio 2CH PCM (default)	<button>Update</button>
INPUT2	Connected	HDMI 1080p@60Hz, Audio 2CH PCM (default)	<button>Update</button>
INPUT3	Disconnected	HDMI 1080p@60Hz, Audio 2CH PCM (default)	<button>Update</button>
INPUT4	Disconnected	HDMI 1080p@60Hz, Audio 2CH PCM (default)	<button>Update</button>

Load User EDID

Select EDID File  Select Destination

## Name

- Displays the name of the input

## HDMI Cable


- Displays the connection status of the input port

## EDID

- EDID selection can be made for each input source device to ensure the correct video and audio resolutions are requested from the SW42DA to the source. The drop down menu contains all of the EDID formats supported, the ability to copy the EDID from another output with a connected display, and also the ability to load up to 2 x user defined EDIDs

## Actions

- The Update button will open a sub menu to configure the following options:



## Name

- The name of the input can be updated by entering a new name into the name field and pressing the Update button

## Load User EDID:

It is possible to upload custom EDID .bin files to the SW42DA if a specific EDID is not listed within the standard formats. A custom EDID file can be generated from a third party EDID generation tool, and uploaded using the Browse and Upload buttons. There are 2 x custom EDID slots available that can be directed at any of the 4 x inputs.

Once a file has been uploaded, it can be selected by using the corresponding USER EDID option.

## Web-GUI - Output

The Output page allows for configuration of the HDMI and Optical outputs.

The outputs can be turned on or off, renamed, and can be set to downmix and scale.

Name	HDMI Cable	Output	Audio Signal	Video	Output Scaling	Actions
OUTPUT1	Connected	ON	Bypass	None	Bypass	<button>Update</button>
OUTPUT2	Disconnected	ON	Downmix 2CH	None	Auto	<button>Update</button>
OPT OUT		ON	Downmix 2CH			<button>Update</button>

### Name

- Displays the name of the Output

### HDMI Cable

- Displays the connection status of the output port

### Output

- Displays if the output is set to either ON or OFF

### Audio Signal

- Set the audio format to either *Downmix 2CH* (for displays that only support 2ch audio) or *Bypass*

### Video

- The SW42DA can detect and display information about the output connection such as the resolution, refresh rate, colour depth and HDR

### Output Scaling

- Set the scaler for the output to either *Auto*, *Force 1080p* or *Bypass*

*Auto*      Output will be automatically set to the best possible video format


*Bypass*      Output bypasses the scaler

*Force 1080p*      Output will be downscaled to 1080p format, with HDCP 1.x compliance

**Web-GUI - Output (continued)**

## Actions

- The Update button will open a sub menu to configure the following options:



## Name


- The name of the output can be updated by entering a new name into the name field and pressing the Update button

## Output

- The output can be turned on or off by using the toggle

# Web-GUI - Audio

The Audio page allows for configuration and fine tuning of the analogue outputs and Dante® audio devices.




## Output Mode:

To select the desired Output Mode, use the dropdown menu.

A table on the following page provides the channel mapping for all 26 modes:

The SW42DA is able to detect the audio format on the currently selected source. It will be displayed under Source Signal and will also output serial and API feedback:



**Please note:** When the Output Mode supports Dolby Atmos Enabled Speakers, the Analogue/Dante® 2 Channel Out will not have the audio downmix function. Please select a mode without Dolby Atmos Enabled Speakers if you need the audio downmix function.

**Please note:** After changing the Output Mode, the Dante® module is rebooted. This takes about 40 seconds for the Dante® Controller to update any changes.

## Web-GUI - Audio (continued)

Output Mode	MULTI CHANNEL OUT								2 CHANNEL OUT	
	L	R	Sub	C	Ls	Rs	Lrs	Rrs	Ltm/DL	Rtm/DR
01: 2.0CH	L	R	-	-	-	-	-	-	DL	DR
02: 2.1CH + Top Middle(2.1.2CH)	L	R	Sub	-	-	-	Ltm	Rtm	DL	DR
03: 2.1CH + Dolby ATMOS Enabled Speaker(2.1.2CH)	L	R	Sub	-	-	-	Le	Re	-	-
04: 3.1CH	L	R	Sub	C	-	-	-	-	DL	DR
05: 3.1CH + Top Middle(3.1.2CH)	L	R	Sub	C	-	-	Ltm	Rtm	DL	DR
06: 3.1CH + Dolby ATMOS Enabled Speaker(3.1.2CH)	L	R	Sub	C	-	-	Le	Re	-	-
07: 4.1CH	L	R	Sub	-	Ls	Rs	-	-	DL	DR
08: 4.1CH + Top Middle(4.1.2CH)	L	R	Sub	-	Ls	Rs	Ltm	Rtm	DL	DR
09: 4.1CH + Dolby ATMOS Enabled Speaker(4.1.2CH)	L	R	Sub	-	Ls	Rs	Le	Re	-	-
10: 4.1CH + Top Rear + Top Front(4.1.4CH)	L	R	Sub	-	Ls	Rs	Ltr	Rtr	Ltf	Rtf
11: 4.1CH + Top Rear + Dolby ATMOS Enabled Speaker(4.1.4CH)	L	R	Sub	-	Ls	Rs	Ltr	Rtr	Le	Re
12: 4.1CH + Dolby ATMOS Enabled Speaker + Top Front(4.1.4CH)	L	R	Sub	-	Ls	Rs	Lse	Rse	Ltf	Rtf
13: 4.1CH + Front & Rear Dolby ATMOS Enabled Speaker(4.1.4CH)	L	R	Sub	-	Ls	Rs	Lse	Rse	Le	Re
14: 5.1CH	L	R	Sub	C	Ls	Rs	-	-	DL	DR
15: 5.1CH + Top Middle(5.1.2CH)	L	R	Sub	C	Ls	Rs	Ltm	Rtm	DL	DR
16: 5.1CH + Dolby ATMOS Enabled Speaker(5.1.2CH)	L	R	Sub	C	Ls	Rs	Le	Re	-	-
17: 5.1CH + Top Rear + Top Front(5.1.4CH)	L	R	Sub	C	Ls	Rs	Ltr	Rtr	Ltf	Rtf
18: 5.1CH + Top Rear + Dolby ATMOS Enabled Speaker(5.1.4CH)	L	R	Sub	C	Ls	Rs	Ltr	Rtr	Le	Re
19: 5.1CH + Dolby ATMOS Enabled Speaker + Top Front(5.1.4CH)	L	R	Sub	C	Ls	Rs	Lse	Rse	Ltf	Rtf
20: 5.1CH + Front & Rear Dolby ATMOS Enabled Speaker(5.1.4CH)	L	R	Sub	C	Ls	Rs	Lse	Rse	Le	Re
21: 6.1CH	L	R	Sub	-	Ls	Rs	Lrs	Rrs	DL	DR
22: 6.1CH + Top Middle(6.1.2CH)	L	R	Sub	-	Ls	Rs	Lrs	Rrs	Ltm	Rtm
23: 6.1CH + Dolby ATMOS Enabled Speaker(6.1.2CH)	L	R	Sub	-	Ls	Rs	Lrs	Rrs	Le	Re
24: 7.1CH	L	R	Sub	C	Ls	Rs	Lrs	Rrs	DL	DR
25: 7.1CH + Top Middle(7.1.2CH)	L	R	Sub	C	Ls	Rs	Lrs	Rrs	Ltm	Rtm
26: 7.1CH + Dolby ATMOS Enabled Speaker(7.1.2CH)	L	R	Sub	C	Ls	Rs	Lrs	Rrs	Le	Re


**CEC Volume Control:**

The SW42DA has the ability to adjust the Master Output volume level through the HDMI-CEC (Consumer Electronics Control) feature, allowing you to control the SW42DA Master Output volume via 3rd party devices connected to the same sink.

For CEC controls to work, connect HDMI Output 1 from the SW42DA to the ARC/eARC port on the sink. Connect 3rd party devices (e.g.: Apple TV, Chromecast, etc) to the other HDMI inputs on the sink.

**Please note:** 3rd party devices connected directly to the SW42DA instead of the sink will not pass CEC commands to the SW42DA.

Pressing the *CEC Volume Control* button will open a sub menu to configure the following options:




## CEC Volume Control (continued)

### CEC Volume Control

- ON / OFF

## Audio Mode Settings:

Pressing the *Audio Mode Settings* button will open a sub menu to configure the following options:



### Dynamic Range Control (DRC)

- ON / OFF / AUTO

Dynamic Range Control is used to adjust the dynamic loudness range of the content on playback to fit the capabilities of playback systems and listener preference. Essentially, low-level signals are boosted, mid-level signals are left untouched, and high-level signals are compressed, thus reducing the overall dynamic range

When set to auto, it will be up to the source to determine when to switch DRC on or off

### Surround Decoder (Upmixer)

- ON / OFF

Surround Decoder Upmixing produces an extended surround sound optimized for your speaker system from audio content with less speaker channels

### Speaker Virtualizer

- ON / OFF

Speaker Virtualizer enables you to access a more immersive entertainment experience from traditional channel-based speaker layouts through digital signal processing including Dolby Atmos height virtualization and surround virtualization


## Group and Channel Output Management:

The Master, Line & Dante® Outputs of the SW42DA are displayed here. The availability of each section and its respective controls will change based on the selected Output mode. The screenshots in this manual are of the SW42DA operating in mode 24.

### Master Output

The Master Output controls the overall output level of the entire system; it can be set from 0% to 100% and acts as a multiplier, scaling the audio up and down proportionally, adjusting the final volume without changing the relative balance between the individual sources. To exclude an output from being adjusted by the Master Output control, set the desired output grouping toggle to OFF.

The Master Output volume can be adjusted by using the corresponding slider and/or volume controls.



## Group and Channel Output Management (continued)

Multichannel Line Output & 2 Channel Line Output

The Multichannel Line Output & 2 Channel Line Output audio source can be selected from the Audio Selection drop down box:

- HDMI / ARC Input
- Dante® Input

The name of the output group and the number of configurable channels will change depending on the Output Mode selected

**Please note:** When the output mode supports Dolby ATMOS Enabled Speakers, the 2 Channel Line Output will not have the audio downmix function.

The channel's volume can be adjusted by using the corresponding slider and/or volume controls

A delay can be set between 0ms and 50ms by the delay slider below the channel. This can be used to rectify lip sync and other similar issues



## Group and Channel Output Management (continued)

### Multichannel Dante® Output & 2 Channel Dante® Output

The Multichannel Dante® Output & 2 Channel Dante® Output IP address is displayed here.

The name of the output and the number of configurable channels will change depending on the Output Mode selected.

**Please note:** When the output mode supports Dolby Atmos Enabled Speakers, the Dante® 2 Channel Output will not have the audio downmix function.

- To set a speaker channel volume independently, set the desired speaker channel grouping toggle to OFF.
- The channel's volume can be adjusted by using the corresponding slider and/or volume controls
- A delay can be set between 0ms and 50ms by the delay slider below the channel. This can be used to rectify lip sync and other similar issues



**Dante® Module Web-GUI:**

Direct configuration of the SW42DA Dante® modules can be achieved by pressing the *Click here to access Web GUI* button which will open an additional web browser window to access the Dante® module's Web-GUI. The default IP of the Dante® modules may differ to the main IP address of the SW42DA. Please check the network settings of the SW42DA within the Settings page.


When initially accessing the Web-GUI of the Dante® Module, a login screen will be displayed. The default login credentials are:

Default Username is: [blustream](#)

Default Password is: [@Bl1s1234](#)

## Web-GUI - Dante® Module Settings

Once logged in, the Settings page will be displayed as shown below. Additional Web-GUI pages become available from within the GUI which can be navigated to by pressing the corresponding icon.



### IP Settings:

#### IP Mode

- Static / DHCP

#### IP Address

- Disabled when in DHCP mode

#### IP Subnet

- Disabled when in DHCP mode

#### TCP Port

- Enable / Disable (default: 8000)

#### Gateway

- Disabled when in DHCP mode

#### Telnet Port

- Enable / Disable (default: 23)

#### Domain name (mDNS)


- mDNS is a protocol used in network environments to resolve hostnames to IP addresses within local networks without the need for a dedicated DNS server. The SW42DA is able to be accessed via the hostname if the IP address is not known.

Press the *Save* button to apply any changes.

To revert to factory default network settings, press the *Set Network Defaults* button.

# Web-GUI - Dante® Module Update

The Update page allows for the firmware of the Dante® module to be upgraded and for the module to be factory reset.



## Firmware Update

- Browse your device for a firmware file to upload to the unit.

## Factory Reset

- Erases all settings and reboots the unit.

## Reboot

- Reboots the unit.

## Web-GUI - Dante® Module Information


The Information page displays the model name, serial number, Web-GUI firmware version and MCU firmware version of the SW42DA. It also displays network configuration, temperature and uptime data.



Information	
Model	SW42DA-DOWNMIX
Firmware Version	V1.1.0c/V2.0.0
DEP SDK	V1.3.3.5_20240814
Hostname	SW42DA-DOWNMIX-272d86
IP Address	10.0.0.78
Subnet Mask	255.255.255.0
Gateway	10.0.0.1
MAC Address	34:D0:B8:27:2D:86
Uptime	0000:07:52:36


## Web-GUI - Users

The Users page allows for configuration of the Guest and User privileges. The SW42DA can be setup with different users, each with their own control privileges. This will enable the Administrator to manage the accessibility of features, including inputs and outputs, for each individual.



Username	Inputs	ARC	Master	Power	Action
guest	1,2,3,4	ON	ON	ON	<button>Update</button> <button>Delete</button>

To create a new user, press the *New User* button to open a sub menu:



Create User

Username:

Password:

Confirm Password:

Power:

ARC:

Inputs:  1  2  3  4

Volume:  Master

Create

Enter a unique username and password, and configure the privileges for that user by toggling and checking/unchecking the desired options. Click the Create button at the bottom of the sub menu to finalise the new user creation.

The new user will appear in the user list. The privileges for that user can then be updated as needed by pressing the *Update* button. The user may be deleted by pressing the *Delete* button.

# Web-GUI - Settings

The Settings page allows for the configuration of the system settings, such as the ability to reboot & factory reset the system, configure network settings, and update the firmware.

## Reset System Settings:

- Returns all device settings to their default state.

## Reboot:

- Reboots the SW42DA

## Web Module Information:

The Web Module Information section displays the network configuration of the SW42DA, and the firmware version of the Web-GUI. The Update button will open a sub menu to configure the network settings of the module, which can be set manually or automatically with DHCP. Press the Update button at the bottom of the sub menu to apply any changes.

## Dante® 7.1ch Module Information

The Dante® 7.1ch Module Information section displays the network configuration of the Dante® 7.1ch Module, the MCU & DEP firmware version and the MAC address of the Dante® module. The Update button will open a sub menu to configure the network settings of the module, which can be set manually or automatically with DHCP. Press the Update button at the bottom of the sub menu to apply any changes.

## Dante® 2ch Module Information

The Dante® 2ch Module Information section displays the network configuration of the Dante® 2ch Module, the MCU & DEP firmware version and the MAC address of the Dante® module. The Update button will open a sub menu to configure the network settings of the module, which can be set manually or automatically with DHCP. Press the Update button at the bottom of the sub menu to apply any changes.

## Device Information:

The Device Information section displays the device name, MCU & DSP firmware version, the domain name of the unit, and the MAC address, and the firmware version of the Web-GUI. The Update button will open a sub menu to configure the following items:




Domain Name:

- Sets the domain name of the SW42DA that can be used to access the Web-GUI without knowing the IP details of the unit.

Press the Update button at the bottom of the sub menu to apply any changes.

## Device Status:

The Device Status sections controls the parameters of the RS-232 serial port as well as provides system information. The Update button will open a sub menu to configure the following items:



Baud rate:

- Selects the desired RS-232 communication baud rate; default is 57600

Telnet Port:


- Sets the Telnet port; default is 23
- Telnet access can be enabled or disabled via the toggle

TCP/IP

- Sets the TCP/IP port; default is 8000
- TCP/IP access can be enabled or disabled via the Toggle

**Advanced System Settings:**

The Advanced System Settings section allows for configuration of the IR mode, CEC, the LCD and front panel buttons. The Update button will open a sub menu to configure the following items:

**IR Mode**

- Set's the operating voltage of the IR ports

**CEC Steps**

- Sets the number of steps to increment or decrement by per CEC command

**IP Control**

- Enable / Disable the IR functionality

**Beep Control**

- Enable / Disable system unit beep sounds

**LCD**

- Enable / Disable the LCD to auto turn off when the unit is powered on

**LCD Pause Time (s)**

- Set the amount of time for the LCD screen to automatically turn off

**PWLED Follow**

- Sets the power LED not follow LCD status (e.g. when the unit is powered on, the power LED is always on)

**Front Panel Buttons**

- Enable / Disable the front panel buttons

**ARC Selection Method**

- The Audio Return Channel (ARC) or Enhanced Audio Return Channel (eARC) on HDMI Output 1 can act as a source or an output
- When set as a source, ARC/eARC will be assigned as input 5 on the SW42DA, resulting in ARC/eARC audio for all audio outputs, but no video signal on HDMI 1 & 2 outputs
- When set as an output, ARC/eARC can be enabled or disabled via a toggle
  - When enabled, HDMI Output 1 will only output video. HDMI Output 2 will output the selected source audio and video. This allows you to use HDMI Output 2 for additional HDMI distribution purposes. ARC/eARC will be output to the Line and Dante® audio outputs
  - When disabled, HDMI Output 1 & 2 won't be affected

## IR Mode

- Set's the operating voltage of the IR ports

## CEC Steps

- Sets the number of steps to increment or decrement by per CEC command

## IP Control

- Enable / Disable the IR functionality

## Beep Control

- Enable / Disable system unit beep sounds

## LCD

- Enable / Disable the LCD to auto turn off when the unit is powered on

## LCD Pause Time (s)

- Set the amount of time for the LCD screen to automatically turn off

## PWLED Follow

- Sets the power LED not follow LCD status (e.g. when the unit is powered on, the power LED is always on)

## Front Panel Buttons

- Enable / Disable the front panel buttons

## ARC Selection Method

- The Audio Return Channel (ARC) on HDMI Output 1 can act as a source or an output
- When set as a source, ARC will be assigned as input 5 on the SW42DA, resulting in ARC audio for all audio outputs, but no video signal on HDMI 1 & 2 outputs
- When set as an output, ARC can be enabled or disabled via a toggle
  - When enabled, HDMI Output 1 will only output video. HDMI Output 2 will output the selected source audio and video. This allows you to use HDMI Output 2 for additional HDMI distribution purposes. ARC will be output to the Line and Dante® audio outputs
  - When disabled, HDMI Output 1 & 2 won't be affected

**Firmware Update:**

Browse your device for a firmware file to upload to the unit.

The Web-GUI module and MCU can both be updated from here, so ensure the desired firmware is selected.

Once the required file has been selected press Update. The upgrade process will start and the progress will be shown on screen.

Once complete a message of 'Upgrade Successful' will be displayed.

**Please note:** Dante® firmware update must be completed within the 'Audio Page' of the SW42DA, or via Dante® Controller.


## Dante® Controller

The Dante® Controller software is required in order to setup and configure the SW42DA as well as control a Dante® network.

Audinate provide extensive training videos and documentation on their website, which can be found here: <http://www.audinate.com/products/software/Dante®-controller>

The SW42DA is seen as two separate Dante® audio products: an 8 channel and 2 channel Dante® device, each with their own settings that can be updated, managed and routed independently.

Upon connecting the SW42DA to a compatible network, the Dante® Controller software should automatically discover the devices. The SW42DA will appear in the Dante® Controller as 'SW42DA-MULTI-xxxxxx' and 'SW42DA-DOWNMIX-xxxxxx'. On the Routing tab, audio can be routed as a matrix between Dante® transmitters and receivers in your system.



All audio channels can be routed independently, but these are intended for a 7.1 channel & a 2 channel downmix, or (if configured) as a 7.1.2 channel or a 5.1.4 channel speaker configuration.

The SW42DA is shipped with its network settings set to obtain an IP Address automatically; if a DHCP server is present on your network, it will provide the SW42DA with an IP Address. If no DHCP server is present then the SW42DA will receive a default IP Address in the 169.254.xxx.xxx range.

## Advanced Dante® Settings


Further settings of the SW42DA can be configured in the Dante® Controller software. Under the Device Info tab, select the SW42DA-MULTI or SW42DA-DOWNMIX to open the Device View window.


Routing		Device Info		Clock Status		Network Status		Events	
Device Name	Model Name	Product Version	Dante Version	Device Lock	Primary Address	Primary Link Speed	Secondary Address	Secondary Link Speed	
SW42DA-DOWNMIX-2736f1	SW42DA-DOWNMIX	1.0.1	1.4.2.1	<input type="checkbox"/>	192.168.0.198	100Mbps	N/A	N/A	
SW42DA-MULTI-2736f2	SW42DA-MULTI	1.0.1	1.4.2.1	<input type="checkbox"/>	192.168.0.199	100Mbps	N/A	N/A	

2 devices      Multicast Audio Bandwidth: 0 bps      Event Log       Clock Status Monitor 

The sample rate and latency can be adjusted under the Device Config tab, while network settings and the IP address can be set under the Network Config tab.

**Please note:** That Dante® products can only transmit or receive audio from other Dante® products that are set up with the same sample rate. A mismatch in sample rate may stop audio from transmitting.





## Specifications

**Video Input Connectors:** 4 x HDMI Type A, 19-pin, female

**Video Output Connectors:** 2 x HDMI Type A, 19-pin, female

**Audio Output Connectors:** 1 x Optical (Toslink), 5 x 5-Pin Phoenix (8ch + 2ch balanced/unbalanced analogue audio), 1 x RJ45, female (100Mbps Dante® network)

**EDID Selection:** 4-pin DIP switch

**TCP/IP Control:** 1 x RJ45, female

**RS-232 Port:** 1 x 3-pin Phoenix

**IR Input Port:** 1 x 3.5mm stereo jack

**Product upgrade:** 1 x Micro USB female

**Dimensions (W x H x D):** 220mm x 214mm x 45mm, without feet or connections

**Shipping Weight:** 2.6kg

**Operating Temperature:** 32°F to 104°F (0°C to 40°C)

**Storage Temperature:** -4°F to 140°F (-20°C to 60°C)

**Power Supply:** Internal 100-240V AC

## Package Contents

- 1 x SW42DA
- 1 x Remote control
- 1 x IR receiver
- 1 x 19" Rack Mounting kit
- 4 x Mounting feet
- 1 x Quick Reference Card
- 1 x IEC Power Cable

## Acknowledgements

Dolby, Dolby Atmos, Dolby Vision and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 2012-2024 Dolby Laboratories. All rights reserved.

For DTS patents, see <http://patents.dts.com>. Manufactured under license from DTS Licensing Limited. DTS, DTS:X, and the DTS:X logo are registered trademarks or trademarks of DTS, Inc. in the United States and other countries. © 2024 DTS, Inc. All rights reserved.

# RS-232 Configuration and Telnet Commands

The SW42DA can be controlled via serial and TCP/IP.

The default RS-232 communication settings are:

Baud rate: 57600

Data bits: 8

Stop bits: 1

Parity bit: none

The following pages list all available serial / IP commands.

## Commonly Used Serial Commands

There are several commands that are commonly used for control and testing:

**STATUS** Status will give feedback on the switcher such as outputs on, type of connection, etc.

**PON** Power on

**POFF** Power off

**OUTON/OFF** Toggling the main output ON or OFF as required

Example: OUTON (This would turn the main output on)

**OUT FRyy** (yy is the input)

Example: OUT FR04 (This would switch the main output to source input 4)

## Common Mistakes

- Carriage return: Some programs do not require the carriage return where as other will not work unless sent directly after the string. In the case of some Terminal software the token <CR> is used to execute a carriage return. Depending on the program you are using this token maybe different. Some other examples that other control systems deploy include \r or 0D (in hex)
- Spaces: Blustream commands do not require space between commands unless specified. There may be some programs that require spacing in order to work.
  - How the string should look is as follows: OUTON
  - How the string may look if spaces are required: OUT{Space}ON
- Baud rate or other serial protocol settings not correct

## RS-232 Configuration and Telnet Commands (continued)

COMMAND	ACTION
?	Print Help Information
HELP	Print Help Information
STATUS	Print System Status And Port Status
FWVER	Print All Soft Version
UPTIME	Print System Uptime
TEMP	Print System Temperature
PON	Power On, System Run On Normal State
POFF	Power Off, System Run On Power Save State
PWLED FOLLOW ON/OFF	ON: Set System Power Led Follow LCD Status OFF: Set System Power Led Not Follow LCD Status In Power On State
REBOOT	Set System And Network Reboot
IR ON/OFF	Set System IR Control On Or Off
IR 5V	Set System IR Is 5V Power Supply Infrared Receiver
IR 12V	Set System IR Is 12V Power Supply Infrared Receiver
KEY ON/OFF	Set System KEY Control On Or Off
BEEP ON/OFF	Set Onboard Beep On Or Off
LCD ON/OFF	Set LCD Always On Or Set LCD Off After No Operation 30 Seconds
LCD DSPT x	Set LCD Display Scroll And Pause Time To x(s) x=[0...10]: Pause Time
RSB x	Set RS232 Baud Rate To x bps x=[0:115200 1:57600
RESET	Reset System To Default Setting
RESET ALL	Reset System And Network To Default Setting (Should Type "Yes" To Confirm)
CEC ON/OFF	Set CEC Volume Control On Or Off
CEC VC BY xx	Set CEC Volume Control By xx xx=01: Group xx=02: Channel
VOL+xx	Increase System Volume xx=[01...100]:Steps xx Can Be Empty(1 Step)
VOL-xx	Decrease System Volume xx=[01...100]:Steps xx Can Be Empty(1 Step)
VOL xx	Set System Volume Value To xx xx=[00...100]:Volume Value
DELAY xx	Set System Delay Time To xx(ms) xx=[00...50]:Delay Time
MUTE ON/OFF	Set Mute On Or Off
MASTER xx ON/OFF	Set Master Output Including/Excluding xx xx=00: All Output Port xx=[01]: Multi Channel Line Out xx=[02]: 2 Channel Line Out xx=[03]: Multi Channel Dante® Out xx=[04]: 2 Channel Dante® Out
IN xx CEC VOL STEPS yy	Set CEC Vol Steps xx=[00...01]:0:ALL yy=[01...10]:CEC Steps

COMMAND	ACTION
OUT xx ON/OFF	Set Output:xx On Or Off xx=00: Select All Output Port xx=01: Select HDMI Output Port 1 xx=02: Select HDMI Output Port 2 xx=03: Select Optical Output Port
OUT xx SCALING yy	Set Output:xx Video Mode yy xx=02: Select Output 2 Port yy=[01]: Set Output 2 Port Video Mode Auto yy=[02]: Set Output 2 Port Video Mode Force 1080p yy=[03]: Set Output 2 Port Video Mode Bypass
OUT xx AUDIO yy	Set Output xx Audio To yy xx=02: Select Output 2 Port xx=03: Select Optical Output Port yy=[01]: Bypass yy=[02]: Downmix 2CH
OUT FR yy	Set Output From Input:yy yy=[01]: Select Input 1 Port yy=[02]: Select Input 2 Port yy=[03]: Select Input 3 Port yy=[04]: Select Input 4 Port yy=[05]: Select ARC Input
OUT xx ARC ON/OFF	Set Output:xx ARC On Or Off xx=01: Select Output 1 Port
ARC MODE xx	Select ARC Mode xx=01: Select ARC As a Source xx=02: Select ARC Toggle On/Off
OUT DRC ON/OFF/AUTO	Set DSP Dynamic Range Control (DRC) Mode
OUT SUD ON/OFF	Set DSP Surround Decoder (Upmixer) On Or Off
OUT SPV ON/OFF	Set DSP Speaker Virtualizer On Or Off

## RS-232 Configuration and Telnet Commands (continued)

COMMAND	ACTION	COMMAND	ACTION
OUT MODE yy	Set Audio Output Mode:yy yy=01: 2.0CH yy=02: 2.1CH + Top Middle(2.1.2CH) yy=03: 2.1CH + Top Middle(2.1.2CH) Dolby ATMOS Enabled Speaker yy=04: 3.1CH yy=05: 3.1CH + Top Middle(3.1.2CH) yy=06: 3.1CH + Top Middle(3.1.2CH) Dolby ATMOS Enabled Speaker yy=07: 4.1CH yy=08: 4.1CH + Top Middle(4.1.2CH) yy=09: 4.1CH + Top Middle(4.1.2CH) Dolby ATMOS Enabled Speaker yy=10: 4.1CH + Top Rear + Top Front(4.1.4CH) yy=11: 4.1CH + Top Rear + Top Front(4.1.4CH) Front Dolby ATMOS Enabled Speaker yy=12: 4.1CH + Top Rear + Top Front(4.1.4CH) Rear Dolby ATMOS Enabled Speaker yy=13: 4.1CH + Top Rear + Top Front(4.1.4CH) Front & Rear Dolby ATMOS Enabled Speaker yy=14: 5.1CH yy=15: 5.1CH + Top Middle(5.1.2CH) yy=16: 5.1CH + Top Middle(5.1.2CH) Dolby ATMOS Enabled Speaker yy=17: 5.1CH + Top Rear + Top Front(5.1.4CH) yy=18: 5.1CH + Top Rear + Top Front(5.1.4CH) Front Dolby ATMOS Enabled Speaker yy=19: 5.1CH + Top Rear + Top Front(5.1.4CH) Rear Dolby ATMOS Enabled Speaker yy=20: 5.1CH + Top Rear + Top Front(5.1.4CH) Front & Rear Dolby ATMOS Enabled Speaker yy=21: 6.1CH yy=22: 6.1CH + Top Middle(6.1.2CH) yy=23: 6.1CH + Top Middle(6.1.2CH) Dolby ATMOS Enabled Speaker yy=24: 7.1CH yy=25: 7.1CH + Top Middle(7.1.2CH) yy=26: 7.1CH + Top Middle(7.1.2CH) Dolby ATMOS Enabled Speaker	OUT xx VOL+yy	Increase Output:xx Volume xx=00: Select All Output Port xx=01: Multi Channel Line Out L xx=02: Multi Channel Line Out R xx=03: Multi Channel Line Out Sub xx=04: Multi Channel Line Out C xx=05: Multi Channel Line Out Ls xx=06: Multi Channel Line Out Rs xx=07: Multi Channel Line Out Lrs xx=08: Multi Channel Line Out Rrs xx=09: 2 Channel Line Out L xx=10: 2 Channel Line Out R xx=11: Multi Channel Dante® Out L xx=12: Multi Channel Dante® Out R xx=13: Multi Channel Dante® Out Sub xx=14: Multi Channel Dante® Out C xx=15: Multi Channel Dante® Out Ls xx=16: Multi Channel Dante® Out Rs xx=17: Multi Channel Dante® Out Lrs xx=18: Multi Channel Dante® Out Rrs xx=19: 2 Channel Dante® Out L xx=20: 2 Channel Dante® Out R xx=21: Multi Channel Line Out Group xx=22: 2 Channel Line Out Group xx=23: Multi Channel Dante® Out Group xx=24: 2 Channel Dante® Out Group xx=25: Master Out yy=[1...100]:Steps yy Can Be Empty (1 Step)
		OUT xx VOL-yy	Decrease Output:xx Volume xx=Same With Above yy=[01...100]: Steps yy Can Be Empty (1 Step)
		OUT xx VOL yy	Set Output:xx Volume Value To yy xx=Same With Above yy=[00...100]: Volume Value
		OUT xx MUTE ON/OFF	Set Output Mute On Or Off xx=Same With Above
		OUT xx DELAY yy	Set Output:xx Delay Time To yy(ms) xx=00: Same With Above yy=[00...50]: Delay Time
		OUT xx CEC VC ON/OFF	Set Output xx CEC Volume Control On Or Off xx=Same With Above
		AUDIO xx FR yy	Set Line Output xx Audio From Input yy xx=01: Select Multi Channel Output Port xx=02: Select 2 Channel Output Port yy=[01]: HDMI/ARC Input yy=[02]: Dante® Input

## RS-232 Configuration and Telnet Commands (continued)

COMMAND	ACTION	COMMAND	ACTION
GROUP zz CHANNEL yy ON/OFF	Set GROUP zz Volume Setting Including/Excluding Channel yy zz=01: Multi Channel Line Out Group zz=02: 2 Channel Line Out Group zz=03: Multi Channel Dante® Out Group zz=04: 2 Channel Dante® Out Group yy=[00]: Select All Channels In The Group (When zz=01: Multi Channel Line Out Group) yy=[01]: L yy=[02]: R yy=[03]: Sub yy=[04]: C yy=[05]: Ls yy=[06]: Rs yy=[07]: Lrs yy=[08]: Rrs (When zz=02: 2 Channel Line Out Group) yy=[01]: L yy=[02]: R (When zz=03: Multi Channel Dante® Out Group) yy=[01]: L yy=[02]: R yy=[03]: Sub yy=[04]: C yy=[05]: Ls yy=[06]: Rs yy=[07]: Lrs yy=[08]: Rrs (When zz=04: 2 Channel Dante® Out Group) yy=[01]: L yy=[02]: R	EDID xx DF zz	Set Input:xx EDID To Default EDID:zz xx=00: Select All Input Port xx=[01...04]: Select One Input Port zz=00: HDMI 1080p@60Hz zz=01: HDMI 1080p@60Hz zz=02: HDMI 1080p@60Hz zz=03: HDMI 1080i@60Hz zz=04: HDMI 1080i@60Hz zz=05: HDMI 1080i@60Hz zz=06: HDMI 1080p@60Hz/3D zz=07: HDMI 1080p@60Hz/3D zz=08: HDMI 1080p@60Hz/3D zz=09: HDMI 4K@30Hz 4:4:4 zz=10: HDMI 4K@30Hz 4:4:4 zz=11: HDMI 4K@30Hz 4:4:4 zz=12: HDMI 4K@60Hz 4:2:0/4K@30Hz 4:4:4 zz=13: HDMI 4K@60Hz 4:2:0/4K@30Hz 4:4:4 zz=14: HDMI 4K@60Hz 4:2:0/4K@30Hz 4:4:4 zz=15: HDMI 4K@60Hz 4:4:4 zz=16: HDMI 4K@60Hz 4:4:4 zz=17: HDMI 4K@60Hz 4:4:4 zz=18: HDMI 4K@60Hz 4:4:4 zz=19: HDMI 4K@60Hz 4:4:4 zz=20: HDMI 4K@60Hz 4:4:4 zz=21: HDMI 4K@60Hz 4:4:4 zz=22: HDMI 4K@60Hz 4:4:4 zz=23: HDMI 4K@60Hz 4:4:4 zz=24: HDMI 4K@60Hz 4:4:4 zz=25: HDMI 4K@60Hz 4:4:4 zz=26: HDMI 4K@60Hz 4:4:4 zz=27: HDMI 4K@60Hz 4:4:4 zz=28: HDMI 4K@60Hz 4:4:4 zz=29: HDMI 4K@60Hz 4:4:4 zz=30: DVI 1280x1024@60Hz zz=31: DVI 1920x1080@60Hz zz=32: DVI 1920x1200@60Hz zz=33: HDMI 1920x1200@60Hz zz=34: User EDID 1 zz=35: User EDID 2 zz=36: EDID Pass-through (Copy From Sink 1)
EDID xx CP yy	Set Input:xx EDID Copy From Output:yy xx=00: Select All Input Port xx=[01...04]: Select One Input Port yy=[01...02]: Select One Output Port	NET DHCP ON/OFF	Set Auto IP(DHCP) On Or Off
		NET IP xxxx.xxxx.xxxx.xxxx	Set IP Address
		NET GW xxxx.xxxx.xxxx.xxxx	Set Gateway Address
		NET SM xxxx.xxxx.xxxx.xxxx	Set Subnet Mask Address
		NET TCPPORT xxxx	Set TCP/IP Port
		NET TCPPORT ON/OFF	Set TCP/IP On Or Off
		NET TN xxxx	Set Telnet Port
		NET TN ON/OFF	Set Telnet On Or Off
		NET RB	Set Network Reboot And Apply New Config!!!
		NET DNS xxxx	Set DNS Domain Name To xxxx

# Certifications

## FCC NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**CAUTION** - changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## CANADA, INDUSTRY CANADA (IC) NOTICES

This Class B digital apparatus complies with Canadian ICES-003. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

## CORRECT DISPOSAL OF THIS PRODUCT

This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.



[www.blustream-us.com](http://www.blustream-us.com)

[www.blustream.com.au](http://www.blustream.com.au)

[www.blustream.co.uk](http://www.blustream.co.uk)